

INSTALLATION QUICK REFERENCE GUIDE

Toyota Integrated Bluetooth® Mobile Phone System

Siemens S66

VEHICLE PROCEDURE

To Add a Bluetooth Connection

1. Select "Option"
2. Press "Info" button
3. Select "Telephone"
4. Select "Settings"
5. Scroll to "Bluetooth"
6. Select "Add Phone"
7. Proceed to Handset Procedure below

To Delete a Bluetooth Connection

1. Press "Info" button
2. Select "Telephone"
3. Select "Settings"
4. Scroll to "Bluetooth"
5. Press "Delete"
6. Select "Phone"
7. Select "Yes"
8. Phone deleted from Bluetooth connection

To Transfer Phonebook

1. Press "Info" button on navigation bezel
2. Select "Telephone"
3. Select "Settings"
4. Scroll to "Transfer Phone Data™"
5. Select "Start Transfer"
6. Proceed to Handset Procedure below

HANDSET PROCEDURE

Initial Installation

1. Select Menu
2. Toggle to settings and select
3. Scroll to more settings and select
4. Select Connectivity
5. Scroll to Bluetooth and select
6. If Bluetooth is not currently turned on you will be prompted to activate Bluetooth. Select Yes.
7. If you wish to edit Bluetooth name select Yes and follow prompts. To continue without changing Bluetooth name select No.
8. Select OK
9. Select ALL
10. Select Bluetooth Handsfree
11. Enter Pass code 1212 and select OK.

To Transfer Phonebook

Note: Contacts can only be transferred one at a time

1. Toggle to address book and select
2. Select entry you wish to transfer
3. Select options
4. Scroll to more options and select
5. Scroll to send and select
6. Scroll to via Bluetooth and select
7. Select known devices
8. Select Bluetooth Handsfree

To Continue A Conversation When Exiting The