

Installation Quick Reference Guide

Toyota Integrated Bluetooth™ Mobile Phone System

SONY ERICSSON T610

VEHICLE PROCEDURE (Prius and Land Cruiser)

TO ADD A BLUETOOTH™ CONNECTION

1. Select "**Option**"
2. Press "**Info**" button
3. Select "**Telephone**"
4. Select "**Settings**"
5. Scroll to "**Bluetooth**"
6. Select "**Add Phone**"
7. Proceed to **Handset Procedure** below

TO DELETE A BLUETOOTH™ CONNECTION

1. Press "**Info**" button
2. Select "**Telephone**"
3. Select "**Settings**"
4. Scroll to "**Bluetooth**"
5. Press "**Delete**"
6. Select "**Phone**"
7. Select "**Yes**"
8. Phone deleted from Bluetooth™ connection

TO TRANSFER PHONEBOOK

1. Press "**Info**" button on navigation bezel
2. Select "**Telephone**"
3. Select "**Settings**"
4. Scroll to "**Transfer Phone Data™**"
5. Select "**Start Transfer**"
6. Select **Overwrite or Add** (New contact)

HANDSET PROCEDURE



INITIAL INSTALLATION

1. Toggle right for Main Menu
2. Select "**Connectivity**"
3. Select "**Bluetooth**"
4. Select "**Turn On**"
5. Select "**Handsfree**"
6. Select "**Yes**" to "Add a handsfree device to use with phone?"
7. "**Handsfree**" device found
8. Enter passkey – **1212**
9. Press "**OK**"
10. Select "**Handsfree**"
11. Select "**Connect**"

TO CONTINUE A CONVERSATION WHEN EXITING THE VEHICLE

1. Exit vehicle
2. Phone will advise that "**Hands free device has failed**" (Bluetooth connection)
3. Phone will display "**Would you like to continue conversation?**"
4. Select "**Yes**" on handset
5. Continue talking using handset

TO TRANSFER PHONEBOOK

1. Select "**Menu**"
2. Select "**Phonebook**"
3. Select "**Advanced**"
4. Select "**Start Transfer**"
5. Select "**Send All**"
6. Select "**Via Bluetooth**"
7. Select "**Handsfree**"

TO CONTINUE A CONVERSATION WHEN ENTERING THE VEHICLE

1. Enter and start vehicle